



2016 Truck Fit Guide

Truck Make	Truck Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
Caterpillar	CT660 with 13,200 lb. Axle				41-230	F-53K3
	CT660 with 20,000 lb. Axle	Up to 2014			41-230	55-104-8 / 55-208 / 2500K
Chevrolet	P-12 Chassis (Solid I-Beam Axle)	1998			41-230	V-917K3
	P-30, & Workhorse P-32				31-140	P-30KB13
	P-30, & Workhorse P-32	2004 - 2005			31-140	P-30KB14
	P-32 Chassis				31-140	P-30KB13
	P-32 Chassis	2004 - 2005			31-140	P-30KB14
	P-37 Chassis				31-140	P-30KB13
	P-37 Chassis	2004 - 2005			31-140	P-30KB14
	P-Cutaway Chassis				31-140	P-30KB13
	P-Cutaway Chassis	2004 - 2005			31-140	P-30KB14
	P-72 Chassis	1996 - 1997			41-230	G-002K1
	P-92 Chassis	1996 - 1997			41-230	G-002K1
	Workhorse P-32 Chassis				31-140	P-30KB13
	Workhorse P-32 Chassis	2004 - 2005			31-140	P-30KB14
	Bluebird Bus	1996			41-230	G-002K2.5
	C-4500 with 1-3/4 inch Tie Rod				41-180	S-124K3
C-5500 with 1-3/4 inch Tie Rod (Will Need New Spring U-Bolt)				41-180	G-002 K3	
C 6500 with 1-5/8 inch Tie Rod				41-230	C-103K2.5	
C-7500 with 1-5/8 inch Tie Rod				41-230	B1 Form	
Ford	F-350 1-Ton Pickups (Tie Rod In Front Of Axle)	1991 & Prior			31-120	E-350K13
	F-350 4X4 Leaf Springs (Gas Or Diesel)	1998 & Prior			31-120	A-314K
	F-350 Diesel	1990 - 1998			31-120	F-323K13
	F-550 Straight Axle	2004			41-140	S-124K2
	F-650 4X2	2002			41-140	G-002K2.5
	L-8000				41-230	55-124-7 / 55-208 / 1750K
	Arrow 8000				41-230	55-104-7 / 55-208 / 1750K
	L9000				41-230	B1 Form
	F-750 (Straight Axle)				41-230	B1 Form
	F-800				41-230	B1 Form
	FT900 - 14,000lb. front axle - Single Steer Box	1997			41-230	G-002K3
Freightliner	School Bus FS 65 with 12,000lb. Axle				41-230	G-002K2
	FI 50				41-230	JD-800K2
	FI 50 Medium Duty	1997 - 1999			41-230	F-126K1
	FI 50 (Drop From Bottom Of Spring To Top Of Tie Rod Distance)	1996			41-230	F-169K2
	FI 50	2000			41-230	F-167K2
	FI 60	1996			41-230	F-104K2.5
	FI 60				41-230	JD-800K2
	FI 60 Medium Duty	1997 - 1999			41-230	F-126K1
	FI 60 (Drop From Bottom Of Spring To Top Of Tie Rod Distance)	1996			41-230	F-169K2
	FI 70 with F961 Rockwell Axle				41-230	R-104K2
	FI 70 with 9,000lb. Front Axle	2000 - 2001			41-230	V-814K2



2016 Truck Fit Guide

Truck Make	Truck Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
Freightliner	FL 80 with F961 Rockwell Axle				41-230	R-104K4
	FL 120	1998			41-230	55-104-7 / 55-208 / 2500K
	FWD	2002			41-230	R-104K4
	CL / CST '12064				41-230	B1 Form
	Cascadia 12,000lb.				41-230	G-002K3
	Columbia				41-230	G-002K3
	M-2 Chassis 8,000lb.				41-180	JD-800K3
	M-2 Chassis 10,000lb. - 12,000lb.				41-180	V-917 K3
	M-2 Chassis 16,000lb.				41-230	55-124-7 / 55-208 / 1750K
	X-Press				41-230	V-814K2
GMC	8500 Trucks				41-230	G-002K3
International	Medium Duty Truck	1994			41-230	F-104K1
	Harvester 4700 with 8,000lb. Front Axle				41-230	V-814K3
	4300 Truck	1999			41-230	V-917K2
	4300 Truck	2012			41-230	G-002K2
	4700	1999			41-230	F-104K3
	4400 Trucks	2003 - 2005			41-230	G-002K3
	4400 Trucks, Ambulance, School Bus	2006 - 2008			41-230	I-002K3
	4500 Trucks	2003 - 2005			41-230	G-002K3
	4500 Trucks, Ambulance, School Bus	2006 - 2008			41-230	I-002K3
	4600 Trucks	2003 - 2005			41-230	G-002K3
	4600 Trucks, Ambulance, School Bus	2006 - 2008			41-230	I-002K3
	4700 Trucks	2003 - 2005			41-230	G-002K3
	4700 Trucks, Ambulance, School Bus	2006 - 2008			41-230	I-002K3
	4900 Truck	1999			41-230	V-917K2
	5500i				41-230	G-002K2
	7400 Trucks				41-230	V-917K4
	7600 Trucks				41-230	55-116-8 / 55-208 / 1750K
	9200-9400 Trucks (check Tie Rod Diameter 1 1/2 - 1 3/4)				41-230	G-002K2 / K3
	D-Series Bus (Diesel Pusher)				41-230	I-001K3
	8600 Trucks				41-230	B1 Form
9900 Trucks				41-230	G-002K3	
ProStar				41-230	G-002K3	
Kenworth	Spicer E-1320 with I Axle & 4 Springs	2000			41-230	K-170K3
	900 with 12,000lb. Axle	2000			41-230	G-002K3.5
	Most	Most			41-230	G-002K3
	T600				41-230	G-002K3 / R-104K4
	T800				41-230	G-002K3 / R-104K4
	W900				41-230	B1 Form
Mack	CH 613				41-230	55-124-6 / 55-208 / 1750K
	Vision					
	CV 713				41-230	55-104-7 / 55-208 / 2500K



2016 Truck Fit Guide

Truck Make	Truck Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
Mack	CTPB 713				41-230	55-124-7 / 55-208 / 2500K
	CXP 613				41-230	G-002K3
	GU 813	2008			41-230	55-124-7 / 55-208 / 2500K
	MR 688 Garbage Truck Chassis (& MRU 613 20,000lb. front axle)				41-230	R-104K4
	RD 688				41-230	R-104K4
	DM				41-230	B1 Form
Peterbilt	Model 330	2000			41-180	W-104K1.5
	Model 330 with 20,000lb. front axle				41-230	R-104K3
	Model 357				41-230	B1 Form
	Model 365	2016			41-230	55-156-7, 55-208, 2000K
	Model 367	2008 - 2014			41-230	R-104K4
	Model 378				41-230	55-124-7 / 55-208 / 2000K
	Model 379	2002 - 2008			41-230	55-124-7 / 55-208 / 1750K
	Model 385				41-230	B1 Form
	Most				41-230	G-002K3
Sterling	LT 9500				41-230	B1 Form
	AT 9500					
	with 20,000lb. front axle				41-230	55-102-7 / 55-208 / 1750K
	LT7501 with 18,000lb. front axle - Twin Steer Boxes	2000			41-230	55-104-15/55-208/12-38-1750K
Volvo	VNL Hendrickson Air Tec				41-230	55-194-6 / 55-208 / 1750K
	VT				41-230	B1 Form
	Conventional Truck Conversion (with 12,000lb. Hendrickson front end)	2006			41-230	H-190K2.5
Western Star	4900 Trucks				41-230	B1 Form
White / GMC	Road Boss with 1-1/2 inch Tie Rod	1981			41-230	V-917K2
Workhorse	W-42 with 1-5/16 inch Tie Rod	2006	Workhorse	W-42	41-140	W-042K1.5

Note: Each Safe-T-Plus Unit Requires a Mounting Hardware Kit to install.



Need Help Finding Which Safe-T-Plus Unit and Mounting Kit You Need?
 Contact Us at support@safe-t-plus.com
 or (800) 872-7233